



® *Light Engineered Displays, Inc.*

Graphic Annunciators \* Water Leak Detection  
Fireman's Smoke Control Panels \* ARA Systems

109 Portwatch Way Wilmington, N.C. 28412 Phone: (800) 251-2512 Fax: (800) 251-9878  
Internet: [www.ledinc.com](http://www.ledinc.com) Email: [sales@ledinc.com](mailto:sales@ledinc.com)

## **I. Normal / Standby Operation**

1. No indicators lit.
2. No switches depressed.
3. No audible alarms sounding.

## **II. Receiving a "Call for Help" at the Master Station**

1. The common "call" switch / indicator lights.
2. The individual "Call Station" switch / indicator lights.
3. The audible alarm sounds a slow beep.

## **III. Acknowledge a "Call for Help"**

1. Push the individual call switch / indicator.
  - a. The individual call switch / indicator light goes out.
  - b. The common call / switch indicator light goes out.
  - c. The "Talk" switch / indicator illuminates.
  - d. The audible alarm is silenced.
  - e. The speaker is connected to the call station and the operator can hear the person requesting help.

## **IV. Talking to the Person Requesting Help**

1. Push the green "Talk" switch / indicator.
2. Begin speaking.
3. Release the "Talk" switch / indicator to hear reply.  
(call station user does not have to press a button to talk or listen.)

## **V. Restore System to Normal**

1. Press the individual call switch / indicator again.
2. The green "Talk" switch / indicator light will go out.
3. System returns to normal.